Resetting the CASIO *fx-9750GII* for testing purposes

1. From the Main Menu, highlight the SYSTEM icon and press EXE or press COS.



2. Press F5 (RSET) to reset the memory. If your screen does not match the one shown, press EXIT until it does.

3. Select F2 (MAIN) to reset the main memories, for testing purposes.



4. Press F1 (Yes) to reset the memory on the calculator.

5. Press EXIT when the calculator is complete.

6. To return to the Main Menu, press MENU.